

ETC, Inc

Updated: October 11, 2006

Breaker Add-On Panel (TB)

<i>TB #</i>	<i>Function</i>	<i>Description</i>
1	Alarm	Input to reset all alarm functions
2	24 VDC	24 VDC
3	Ground	Ground
4	SYS-	LDCR pickup negative
5	SYS+	LDCR pickup positive
6	62F	Overlap Form A contact
7	62F	Overlap Form A contact
8	LDRV2	Form A contact (call factory)
9	LDRV2	Form A contact
10	Load Disconnect	Form A
11	“	Common (Load disconnect)
12	“	Form B Load Disconnect
13	VOUT	Form A (KW trip feature)
14	VOUT	Form A (KW trip feature)
15	ALARM	Form A (any alarm features active)
16	ALARM	Form A (any alarm features active)
17	CTR	Hot Normally opened
18	CTR	Hot Normally closed
19	120 HOT	120 vac
20	120 HOT	120 vac
21	NEUTRAL	Neutral (120)
22	NEUTRAL	Neutral (120)
23	E-NEU	Neutral from Emergency transformer
24	E-120	120 vac from Emergency transformer
25	N-NEU	Neutral from Normal transformer
26	N-120	120 vac from Normal transformer

Table 8